

### Kozy™ Assemblies

#### Purpose

- ▶ Insulated pipe blankets, valve covers, and probe jackets to help prevent liquid condensation of the sample by insulating from the extraction point on the pipeline all the way to probe outlet.



#### Kozy™ Assemblies

- ▶ Designed to fit Genie® Membrane Probe Regulator™ Models GPR and GPRiL
- ▶ Helps to comply with the API 14.1 and GPA 2166 standards regarding maintaining the temperature of the sample 30°F above the hydrocarbon dew point at all times.

\*See the Kozy™ Assemblies product sheet for additional information.